












BRASS COUPLINGS FOR AIR BRAKE HOSE

HOSE COUPLING WITH SPRING GUARD	PART NUMBER	HOSE I.D. IN.	MALE PIPE THREAD IN.	SLEEVE	PART NUMBER	HOSE I.D. IN.
	ABB-6-4WS	3/8	1/4		ABB-6-SL	3/8
	ABB-6-6WS	3/8	3/8		ABB-8-SL	1/2
	ABB-6-8WS	3/8	1/2			
	ABB-8-6WS	1/2	3/8			
SPRING GUARD				SHELL		
	ABB-6-SG	3/8			ABB-6-81	3/8
	ABB-8-SG	1/2			ABB-8-81	1/2
HOSE COUPLING				SHELL FOR SPRING GUARD		
	ABB-6-4	3/8	1/4		ABB-6-82	3/8
	ABB-6-6	3/8	3/8		ABB-8-82	1/2
	ABB-6-8	3/8	1/2			
	ABB-8-6	1/2	3/8			
HOSE SPLICER				GLAD HANDS		
	ABB-6-6SP	3/8	3/8		VGB-9	

DRAIN VALVES

	PART NUMBER	PIPE THREAD IN.	OPENING		PART NUMBER	PIPE THREAD IN.	OPENING
	DV320-2	1/8	11/64		DV41-2	1/8	7/32
	DV320-4	1/4	1/4		DV41-4	1/4	1/4
	DV320-6	3/8	11/32		DV41-6	3/8	11/32
	DV320-8	1/2	13/32		DV41-8	1/2	7/16
	DV200-2	1/8	7/32				
	DV200-4	1/4	5/16				
	DV200-6	3/8	11/32				

